



Member of **Sumitomo** Drive Technologies




**Quick Start Guide**

# OPTIDRIVE™ coolvert

AC Variable Speed Drive

7.0 – 20.0A 200V Single Phase Input

14.0 – 58.0A 400V Three Phase Input



Please scan the QR code  
to access the complete User Manual

Or visit  
[www.inverterekdrives.com/coolvert/documentation](http://www.inverterekdrives.com/coolvert/documentation)



## 1 IMPORTANT SAFETY INFORMATION

Please read the IMPORTANT SAFETY INFORMATION below, and all Warning and Caution information elsewhere.



**Danger:** Indicates a risk of electric shock, which, if not avoided, could result in damage to the equipment and possible injury or death.

This variable speed drive product (Optidrive) is intended for professional incorporation into complete equipment or systems as part of a fixed installation. If installed incorrectly it may present a safety hazard. The Optidrive uses high voltages and currents, carries a high level of stored electrical energy, and is used to control mechanical plant that may cause injury. Close attention is required to system design and electrical installation to avoid hazards in either normal operation or in the event of equipment malfunction. Only qualified electricians are allowed to install and maintain this product.

System design, installation, commissioning and maintenance must be carried out only by personnel who have the necessary training and experience. They must carefully read this safety information and the instructions in this Guide and follow all information regarding transport, storage, installation and use of the Optidrive, including the specified environmental limitations.

Do not perform any flash test or voltage withstand test on the Optidrive. Any electrical measurements required should be carried out with the Optidrive disconnected. Internal surge arrestors are fitted, intended to protect against damage due to mains borne spikes, which will result in the product failing the flash test.

Electric shock hazard! Disconnect and ISOLATE the Optidrive before attempting any work on it. High voltages are present at the terminals and within the drive for up to 10 minutes after disconnection of the electrical supply. Always ensure by using a suitable multimeter that no voltage is present on any drive power terminals prior to commencing any work.

Where supply to the drive is through a plug and socket connector, do not disconnect until 10 minutes have elapsed after turning off the supply.

Ensure correct earthing connections and cable selection as per defined by local legislation or codes. The drive may have a leakage current of greater than 3.5mA; furthermore the earth cable must be sufficient to carry the maximum supply fault current which normally will be limited by the fuses or MCB. Suitably rated fuses or MCB should be fitted in the mains supply to the drive, according to any local legislation or codes.

Do not carry out any work on the drive control cables whilst power is applied to the drive or to the external control circuits.



**Danger:** Indicates a potentially hazardous situation other than electrical, which if not avoided, could result in damage to property.

Within the European Union, all machinery in which this product is used must comply with Directive 98/37/EC, Safety of Machinery. In particular, the machine manufacturer is responsible for providing a main switch and ensuring the electrical equipment complies with EN60204-1.

The level of integrity offered by the Optidrive control input functions – for example stop/start and maximum speed, is not sufficient for use in safety-critical applications without independent channels of protection. All applications where malfunction could cause injury or loss of life must be subject to a risk assessment and further protection provided where needed.

The driven motor can start at power up if the enable input signal is present.

The STOP function does not remove potentially lethal high voltages. ISOLATE the drive and wait 10 minutes before starting any work on it. Never carry out any work on the Drive, Motor or Motor cable whilst the input power is still applied.

The Optidrive can be programmed to operate the driven motor at speeds above or below the speed achieved when connecting the motor directly to the mains supply. Obtain confirmation from the manufacturers of the motor and the driven machine about suitability for operation over the intended speed range prior to machine start up.

Do not activate the automatic fault reset function on any systems whereby this may cause a potentially dangerous situation.

Optidrives are intended for indoor use only.

When mounting the drive, ensure that sufficient cooling is provided. Do not carry out drilling operations with the drive in place, dust and swarf from drilling may lead to damage.

The entry of conductive or flammable foreign bodies should be prevented. Flammable material should not be placed close to the drive.

Relative humidity must be less than 95% (non-condensing) for the front of the drive.

Ensure that the supply voltage, frequency and no. of phases (1 or 3 phase) correspond to the rating of the Optidrive as delivered.

Never connect the mains power supply to the Output terminals U, V, W.

Do not install any type of automatic switchgear between the drive and the motor. This may cause the drive protection to activate, resulting in a trip and loss of operation.

Wherever control cabling is close to power cabling, maintain a minimum separation of 100 mm and arrange crossings at 90 degrees.

Ensure that all terminals are tightened to the appropriate torque setting.


Do not attempt to carry out any repair of the Optidrive. In the case of suspected fault or malfunction, contact your local Invertek Drives Sales Partner for further assistance.

## 2 PRODUCT INTRODUCTION

The product range has been specifically designed for OEM and machine-builders alike with through panel mounting and cold-plate technology options available. The drive has no built-in keypad display but the status of the drive is indicated by 2 LED's on the front of the drive.

### 2.1. Identifying the Drive by Model Number

Each drive can be identified by its model number, shown below. The model number is on the shipping label, the drive rating label on the upper surface of the drive and on the front surface on the product identifier. The model number includes the drive and factory fitted options.



#### 2.1.1. Model Variants

##### 200 – 240V +/-10% Single Phase Input

Model Code	Frame	kW	HP	Amps
CV-220070-1FHP	2	1.5	2	7.0
CV-220120-1FHP	2	3	3	12.0
CV-220160-1FHP	2	4	5.5	16.0
CV-220200-1FHP	2	5.5	7.5	20.0

##### 380 – 480V +/-10% Three Phase Input

Model Code	Frame	kW	HP	Amps
CV-240140-3FHE	2	5.5	7.5	14
CV-240180-3FHE	2	7.5	10	18
CV-240240-3FHE	2	11	15	24
CV-340300-3FHE	3	15	20	30
CV-340390-3FHE	3	18.5	25	39
CV-440460-3FHE	4	22	30	46
CV-440580-3FHE	4	30	40	58

Replace 'H' with 'C' for coldplate version.

## **3.1. Mechanical Installation**

### **3.1.1. General**

- The Optidrive Coolvert has been designed to be installed in a suitable enclosure. The drive can be through panel mounted or mounted directly onto the back of a panel using the appropriate mounting kit.
- Using the drive as a template, or the dimensions shown below, mark the locations for drilling.
  - Ensure that when mounting locations are drilled, the dust from drilling does not enter the drive.
  - Mount the drive to the cabinet backplate using suitable mounting screws.
  - Position the drive, and tighten the mounting screws securely.
- The front of the drive is IP20 and must be installed in a pollution degree 1 or 2 environment only.
- In any environments where the conditions require it, the enclosure must be designed to protect the drive against ingress of airborne dust, corrosive gases or liquids, conductive contaminants (such as condensation, carbon dust, and metallic particles) and sprays or splashing water from all directions.
- Enclosures should be made from a thermally conductive material.
- Do not mount flammable material close to the Optidrive.
- Ensure that the minimum cooling air gaps, as detailed in section Ventilation and clearance.

### **3.1.2. Before Installation**

- Carefully Unpack the Optidrive and check for any signs of damage. Notify the shipper immediately if any exist.
- Check the drive rating label to ensure it is of the correct type and power requirements for the application.
- To prevent accidental damage always store the Optidrive in its original box until required. Storage should be clean and dry and within the temperature range  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$ .


### **3.1.3. UL Compliant Installation**

Note the following for UL-compliant installation:

- The heatsink variants of the Coolvert are cUL listed whereas the coldplate variants are cUR recognised as they require additional thermal devices to operate.
- For an up to date list of UL compliant products, please refer to UL listing E226333.
- The drive must be operated within ambient the specified temperature range of  $(-20$  to  $+60^{\circ}\text{C}$ , deratings may be required.)
- The front of the drive is IP20, installation is required in a pollution degree 1 environment.
- The rear of the drive is IP55, installation in a pollution degree 2 environment is permissible.
- If the drive is through panel mounted, ensure the correct environment is maintained for each section of the drive as indicated below.
- If the drive is mounted directly onto the back plate, the whole installation is required in a pollution degree 1 environment.
- UL Listed ring terminals / lugs must be used for all bus bar and grounding connections.
- All 400V frame size 2 drives should use 35 Amp fast acting fuses type Little Fuse L70QS035. All other drives should use fast acting fuses type J.


## 3.2. Mechanical Installation

### 3.2.1. Frame Size 2 Heatsink drives




A		B		C		D		E		F		G		H		J		K	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in								
226.3	8.9	215.2	8.5	201.4	7.9	165.3	6.5	144.8	5.7	182	7.2	177	6.96	71.7	2.82	104.4	4.11	145	5.7

### 3.2.2. Frame Size 2 Coldplate drives




A		B		C		D		E		F		G		H		J	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
226.3	8.9	215.2	8.5	201.4	7.9	165.3	6.5	90	3.5	37.7	1.48	113.9	4.48	104.4	4.11	9.5	0.37

### 3.2.3. Frame Size 3 Heatsink drives




A		B		C		D		E		F		G		H		J		K	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
277.5	10.9	262.6	10.3	247.2	9.7	193.6	7.6	168.9	6.6	224.0	8.8	200.3	7.9	84.3	3.3	116.0	4.6	170.0	6.7

### 3.2.4. Frame Size 3 Coldplate drives




A		B		C		D		E		F		G	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
277.8	10.9	262.6	10.3	168.9	6.6	110.0	4.3	9.8	0.3	126.1	4.9	194.1	9.1

### 3.2.5. Frame Size 4 Heatsink drives



A		B		C		D		E		F		G		H		J		K	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
310	12.2	336	13.3	364	14.3	239.5	9.4	150	5.9	291.5	11.5	230.6	9.1	98	3.9	133	5.2	209.5	8.2

### 3.2.6. Frame Size 4 Coldplate drives




A		B		C		D		E		F		G		H	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
310	12.2	337	0.88	293.5	11.6	20.4	0.8	239.5	9.4	211	8.3	230.7	9.1	97.7	3.8

### 3.2.7. Panel Mounting with Panel Mounting Kit


If the installation does not lend itself to through panel mounting, the drive can be mounted to a back-plate of a panel using the optional panel mounting kit.

#### Size 2






A		B		C		D		E		F		G	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
215.2	8.47	42.7	1.68	80	3.15	165.3	6.5	73.7	2.9	228	8.98	179	7.04

#### Size 3



A		B		C		D		E		F		G	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
266.0	10.5	46.8	1.85	100	3.9	193.3	7.6	84.3	3.3	282	11.1	200.3	7.9

### Size 4






A		B		C		D		E		F		G		H	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
310	12.2	336	13.2	364	14.3	239.5	9.4	150	5.9	363.5	14.3	233.5	9.2	100.4	4

### 3.2.8. Through Panel Mounting




Through panel mounting is the most efficient installation in terms of both panel space and thermal management. With the heatsink protruding through the back of the electrical panel, the heat generated by the drive will be exhausted outside of the electrical panel.

### Size 2






A		B		C		D		E		F		G		H		J	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
226.3	8.9	15.6	0.61	184	7.24	15.6	0.61	165.3	6.5	147	5.78	177	6.96	71.7	2.82	104.4	4.11

### Size 3



A		B		C		D		E		F		G		H		J	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
277.5	10.9	18.8	0.75	227.1	8.94	16.7	0.65	193.6	7.6	173.1	6.8	200.3	7.9	84.3	3.3	116	4.6


### Size 4



A		B		C		D		E		F		G		H	
mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
310	12.2	336	13.2	364	14.3	239.5	9.4	150	5.9	363.5	14.3	233.5	9.2	100.4	4

### 3.2.9. Ventilation and Clearances

In order for the drive to maintain its temperature, a minimum clearance is required around the drive as shown in the diagram below:



Frame Size	W		X		Y		Z*	
	mm	in	mm	in	mm	in	mm	in
2	20	0.787	10	0.394	10	0.394	100	3.94
3	20	0.787	20	0.787	20	0.787	100	3.94
4	20	0.787	20	0.787	20	0.787	100	3.94

**NOTE** The maximum dimensions above for X, Y & Z should be observed regardless of the installation method. Value 'Z' is not applicable to the coldplate variant. These dimensions are the absolute minimum recommended clearances to allow sufficient air flow. The enclosure itself must be significantly wider or taller than the values given above in at least one direction.

### 3.2.10. Product Weights

Frame Size	Product Weights	
2	400V Heatsink	3.05 kg
	230V PFC Heatsink (7/12A)	3.4 kg
	230V PFC Heatsink (16/20A)	3.74 kg
	400V Coldplate	2.03 kg
	230V PFC Coldplate	2.4 kg
3	All Heatsink Drives	5.0 kg
	All Coldplate Drives	3.1 kg
4	All Heatsink Drives	9.5 kg
	All Coldplate Drives	5.0 kg


### 3.2.11. Tightening Torques

Frame Size	Required Torque		
2	Control Terminals	0.5 Nm	4.5 lb in
	Power Terminals	1 Nm	9.0 lb in
3	Control Terminals	0.5 Nm	4.5 lb in
	Power Terminals	2 Nm	18 lb in
4	Control Terminals	0.5 Nm	4.5 lb in
	Power Terminals	2 Nm	18 lb in

## 3.2. Connection Diagram

All power terminal locations are marked directly on the product with AC power input and motor connections located at the bottom of the unit.

### 3.2.1. Electrical Power Connections



### 3.2.2. Incoming Power Connection

#### Cable Selection

- For 1 phase supply, the mains power cables should be connected to L1 /L, L2/N.
- For 3 phase supplies, the mains power cables should be connected to L1, L2, and L3. Phase sequence is not important.
- The cables should be dimensioned according to any local codes or regulations. Maximum dimensions are given in section 6.1. *Detailed Product Rating Tables on page 21.*

#### Protective Earth Conductor

- The cross-sectional area of the PE Conductor must be at least equal to that of the incoming supply conductor and connected to the drives main earth terminal..

#### Fuse / Circuit Breaker Selection


- Suitable fuses to provide wiring protection of the input power cable should be installed in the incoming supply line, according to the data in section 6.1. *Detailed Product Rating Tables on page 21.* The fuses must comply with any local codes or regulations in place. In general, type gG (IEC 60269) or UL type J fuses are suitable; however in some cases type aR fuses may be required. The operating time of the fuses must be below 0.5 seconds. All 400 Volt drives should be protected with fast acting fuses of the type L70QS035 by Littelfuse for UL compliance.
- Where allowed by local regulations, suitably dimensioned type B MCB circuit breakers of equivalent rating may be utilised in place of fuses, providing that the clearing capacity is sufficient for the installation.
- The maximum permissible short circuit current at the Optidrive Power terminals as defined in IEC60439-1 is 100kA.

#### Motor Connection

- The motor should be connected to the Optidrive U, V, and W terminals using a suitable 3 or 4 core cable. Where a 3 core cable is utilised, with the shield operating as an earth conductor, the shield must have a cross sectional area at least equal to the phase conductors when they are made from the same material. Where a 4 core cable is utilised, the earth conductor must be of at least equal cross sectional area and manufactured from the same material as the phase conductors.
- The motor earth must be connected to one of the Optidrive earth terminals.
- Maximum permitted motor cable length for all models: 10 metres shielded, 20 metres unshielded.

#### Power Connections

230V Single Phase Variants				400V 3-Phase Variants			
Power Earth / Ground	L1 (200VAC)	Neutral		Power Earth / Ground	Supply L1	Supply L2	Supply L3
E	L	N		E	L1	L2	L3
Power Earth / Ground	Motor U Phase	Motor V Phase	Motor W Phase	Power Earth / Ground	Motor U Phase	Motor V Phase	Motor W Phase
E	U	V	W	E	U	V	W





### 3.3. Control Wiring


The Optidrive Coolvert has pluggable control terminals to support easy installation. There are three pluggable control terminal blocks split into:

- Serial Communications (T1-T3)
- Inputs (T5 – T9)
- Output Relay (T10 – T11)


#### P1-11 = 0 - Modbus control




#### P1-11 = 1 or 2 Terminal mode



#### P1-11 = 3 Internal PI mode



### P1-11 = 4 Slave mode




### 3.3.1. Safe Torque Off

For information covering the STO function refer to section 3.3.4 in the main user guide.

The STO input is a hardware enable for the drive. If your application does not require the Safe Torque Off function, it will be necessary to link terminal 4 to terminal 8 and separately terminal 7 to terminal 9 as per the diagram below:

### P1-11 = 0



## 4 SET-UP AND OPERATION

### 4.1. Basic Checks Before Commissioning

It is vitally important to ensure that the Coolvert that you have purchased is suitable for the supply that you intend to connect it to, as is the importance of ensuring that this is appropriate for the motor to be connected to.

The motor nameplate data needs to be entered accurately before attempting to run the motor. The format of the information can vary depending on the technology of the motor. It is very important to ensure that the data entered is in the correct format. A common mistake is to enter an incorrect value for the back emf of a permanent magnet motor at rated speed as it can be written as a peak voltage, rms voltage and phase to phase voltage, line voltage and so on.

#### 4.1.1. Access to Parameters

The drive parameters can be accessed via one of the following methods:

1. ModBus Communications
2. Optipad - Optional TFT Keypad
3. OptiTools - Drive Setup Software
4. Optistick Smart - Bluetooth communications

#### 4.1.2. Motor Type and Control Mode

Par.	Modbus Address	Description	Def	Min	Max	Unit	R/W
5-01	501	Motor Control Mode – select according to the motor connected to the drive: 0: BLDC Vector Speed Control 1: Permanent Magnet Vector Speed Control 2: Induction Motor Vector Speed Control (CT) 3: Induction Motor Vector Speed Control (VT) 4: Induction Motor V/F 5: Synchronous Reluctance Vector Speed Control 6: LSPM Speed Control	0	0	6	-	R/W

#### 4.1.3. Motor Name-plate Data

Par.	Modbus Address	Description	Def	Min	Max	Unit	R/W
1-07	107	Motor Rated Voltage (phase-to phase rms) OR Back EMF at Rated Speed for permanent magnet motor types (phase to phase rms)	DD	DD	DD	V	R/W
1-08	108	Motor Rated Current (nominal)	DD	DD	DD	A	R/W
1-09	109	Motor Rated Frequency at Rated Speed (nominal)	180	20	500	Hz	R/W
1-10	110	Motor Rated Speed at Rated Frequency	60	0	500	rps	R/W
7-03	703	Motor Stator Resistance (Rs) This is the motor phase to phase resistance value in ohms.	DD	0.00	655.35	ohm	R/W
7-04	704	Motor Stator Inductance (Lsd) For induction motors: phase stator inductance value. For permanent magnet motors: phase d-axis stator inductance in Henry (H).	DD	0.0	655.35	mH	R/W
7-05	705	Motor Stator Inductance (Lsq) For permanent magnet motors : phase d-axis stator inductance in Henry (H).	DD	0.0	655.35	mH	R/W

#### 4.1.4. Operating Limits and Ramp Rates

Par.	Modbus Address	Description	Def	Min	Max	Unit	R/W
1-01	101	Maximum Motor Speed	60	P1-02	500	Rps	R/W
1-02	102	Minimum Motor Speed	20-	0	P1-01	Rps	R/W
1-03	103	Acceleration Ramp Time from Orps to Rated Speed	5.0	0	6000	s	R/W
1-04	104	Deceleration Ramp Time from Rated Speed to Orps	5.0	0	6000	s	R/W
5-06	506	Motor Switching Frequency (24 x max frequency)	DD	DD	DD	kHz	R/W
5-07	507	Maximum Torque / Current Limit	110	20	130	%	R/W
5-18	518	Maximum Peak Output Current	Drive rating dependant			Apk	R/W

#### 4.1.5. Start-up Sequence

Par.	Modbus Address	Description	Def	Min	Max	Unit	R/W
2-01	201	Start Speed 1	30	P1-02		Rps	R/W
2-02	202	Start Speed 1 Time	0	0	600	s	R/W
2-03	203	Start Speed 1 Acceleration Ramp Rate 0 RPS to rated speed	5.0	0	6000	s	R/W
2-04	204	Start Speed 2	30	P1-02		Rps	R/W
2-05	205	Start Speed 2 Time	0	0	600	s	R/W
2-06	206	Start Speed 2 Acceleration Ramp Rate 0 RPS to rated speed	5.0	0	6000	s	R/W
2-07	207	Start Speed 3	30	P1-02		Rps	R/W
2-08	208	Start Speed 3 Time	0	0	600	s	R/W
2-09	209	Start Speed 3 Acceleration Ramp Rate 0 RPS to rated speed	5.0	0	6000	s	R/W

If the start-up sequencing (or part of the start-up sequencing) is not required, set that Start Speed Time to 0s to disable that function. e.g. if you want to have one part of the start up sequence, set Start Speed 1 (P2-01) to the desired speed in rps, set the time for the motor to sit at speed 1 in P2-02 and set the desired ramp rate in P2-03 – then ensure that P2-05 and P2-08 are both set to 0s. On start-up in this example, the drive will ramp the speed set in P2-01 using the ramp rate set in P2-03 for a duration set in P2-02 before then following the chosen speed reference.

**NOTE** The ramp rates here are entered in seconds per rated speed of the motor (e.g. 5.0s to go from 0rps to 60rps) where 60rps is the compressor rated speed..

#### 4.1.6. Re-start Blocking

Par.	Modbus Address	Description	Def	Min	Max	Unit	R/W
2-10	210	Minimum Off Time	0	0	6000	s	R/W
2-11	211	Minimum On Time	0	0	6000	s	R/W
2-12	212	Re-start Delay (Start-to-start Delay)	0	0	6000	s	R/W
2-13	213	Re-start Function	Edge-r	0	Auto-9	-	R/W

**NOTE** Setting the minimum on time can mean that the drive will continue to run when the stop command is given. Removal of the STO signal will override any other command.

#### 4.1.7. Control Mode

Par.	Modbus Address	Description	Def	Min	Max	Unit	R/W
<b>1-11</b>	111	Command Source 0: Modbus Mode 1: Terminal Control 2: Terminal Control (AI1 Start) 3: User PID Mode 4: Slave Mode	0	0	4	-	R/W
<b>1-05</b>	105	Stop Mode 0: Ramp to Stop 1: Coast to Stop 2: AC Flux Braking (IM Motor only) 3: Ramp to Minimum Speed then Coast to Stop	0	0	3	-	R/W

The primary command source setting in P1-11 makes a significant difference to how the drive is operated or controlled. The following table provides an overview of how the control commands vary for each setting.

P1-11	Drive Enable	Run/Stop	Speed Ref.	Ramps	Fault reset	Crankcase Heating
0 – Modbus	Safety (STO)	Modbus	Modbus	Parameters	DI1 / Modbus	Modbus
1 – Terminal	Safety (STO)	DI1	AI1	Parameters	DI1	STO / Modbus
2 – Terminal AI Start	Safety (STO)	AI1 > 10% / AI1 < 5%	AI1	Parameters	DI1	DI1 / Modbus
3 – User PI	Safety (STO)	DI1	PI Output	Parameters	DI1	STO / Modbus
4 – Slave Mode	Safety (STO)	Master	Master	Parameters	DI1	DI1 / Modbus

## 5.1. Trips

Fault Code	No.	Description	Suggested Remedy
no-FLt	00	No Fault or No Trip	No fault in trip log – no problem with the drive
O-I	03	Instantaneous over current	High current from either – short-circuit on the drive output / acceleration ramps too short / incorrect motor data. <b>NOTE</b> Setting the maximum peak motor current too low in P5-18 could also lead to this trip.
I-Lt-trP	04	Motor Thermal Overload (I2t)	Drive has been delivering more than the configured motor rated current for a period of time – check the operating point of the compressor
P5-trP	05	Power stage trip	Hardware fault, contact the supplier of the drive
O-UoLt	06	Over voltage on DC bus	DC Bus Overvoltage from either - the supply voltage is too high, a spike in the supply voltage, motor instability, try setting P1-05 = 3
U-UoLt	07	Under voltage on DC bus	Usually caused by the supply voltage dropping too low – check connections and voltage at the drive terminals
O-t	08	Heatsink over temperature	Check the ambient temperature, check that the ventilation is not restricted, check the cooling system for the coldplate version
U-t	09	Under temperature	Drive heatsink temperature is too low
P-dEF	10	Factory Default parameters have been loaded	Warning to advise that the drive has been returned to factory defaults
E-tr iP	11	Safety circuit momentarily opened during drive running	Check the wiring of the STO circuit and any switches or devices within that circuit. Ensure that any intermediate devices are not activating momentarily during drive operation.
5C-ObS	12	Optibus comms loss	Loss of communications between drive and remote keypad or PC tools
FLt-dc	13	DC bus ripple too high	Check for supply phase imbalance or phase loss
P-L0SS	14	Input phase loss trip	Input phase loss trip – similar to FLt.dc above
h O-I	15	Instantaneous over current on drive output	Hardware overcurrent on drive output – similar to O-I trip above
tH-FLt	16	Faulty thermistor on heatsink	If the drive heatsink temperature is within limits, contact the supplier of the drive
dRtR-F	17	Internal memory fault (IO)	If not coinciding with a firmware upgrade procedure, contact the supplier of the drive
4-20 F	18	4-20mA Signal Lost	Analogue input configured for 4-20mA but less than 3mA detected on drive terminals
dRtR-E	19	Internal memory fault (DSP)	If not coinciding with a firmware upgrade procedure, contact the supplier of the drive
U-dEF	20	User Default Parameters Loaded	User Default Parameters Loaded
F-Ptc	21	Motor PTC thermistor trip	Drive configured to monitor motor temperature through the PTC and resistance increases above 2.5k
FRn-F	22	Cooling Fan Fault	Drive cooling fan not running at demanded speed – check for any blockages in the cooling fan
O-hERt	23	Environmental temperature too high	Check ambient temperature and ventilation system
OUE-F	26	Drive output fault	Check for wiring faults, loose connections or badly terminated cables between the drive and the motor

<b>Fault Code</b>	<b>No.</b>	<b>Description</b>	<b>Suggested Remedy</b>
<i>Sto-F</i>	29	Safety circuit momentarily opened during drive running	Check the wiring of the STO circuit and any switches or devices within that circuit. Ensure that any intermediate devices are not activating momentarily during drive operation.
		Slow rising edge on 24V supply	Can happen if an external 24V supply is used and the voltage ramps up slowly on power-up. Could also happen if the drive 24V rail is overloaded and collapses momentarily, check the loading of the 24V rail and all control connections.
		Safety input circuit error	Contact the supplier of the drive for further advice
<i>SPd Err</i>	31	Locked Rotor	A speed error has been detected (Locked Rotor)
<i>RtF-D1</i>	40	Measured motor stator resistance varies between phases	Check the motor wiring, disconnect the drive and measure the phase to phase resistance from the motor cable
<i>RtF-D2</i>	41	Measured motor stator resistance is too large	Check the motor wiring, disconnect the drive and measure the phase to phase resistance from the motor cable and refer to motor datasheet
<i>RtF-D3</i>	42	Measured motor inductance is too low	Check the motor wiring
<i>RtF-D4</i>	43	Measured motor inductance is too large	Check the motor wiring
<i>RtF-D5</i>	44	Measured motor parameters are not convergent	Check the motor wiring
<i>OUT-Ph</i>	49	Motor output phase loss	Check the motor wiring
<i>SC-FD1</i>	50	Modbus comms loss fault	Check the Modbus wiring, ensure that the 0V common is used, ensure that the communication wiring is kept away from any power wiring

## 5.2. Status LED Indication

Two LEDs are used to indicate the drive status as follows:

<b>Drive Status</b>	<b>LED 1 Status</b>		<b>LED 2 Status</b>
	<b>Green</b>	<b>Red</b>	<b>Yellow</b>
Stop	Slow flashing	Off	Off
Inhibit	Slow Flashing	Off	Slow Flashing alternate
Running	Constant On	Off	Slow flashing if in overload
Crankcase Heating Active	Slow Flashing	Off	Constant On
Standby	Constant On	Off	Blink every 3s
Trip / Fault	Off	Constant On	Off
Internal Comms Loss	Off	Blink every 3s	Off
Oil Return Active	Constant On	Off	Fast Flashing Yellow
Optistick Transfer Pass	Fast Flashing 2s	Off	Off
Optistick Transfer Fail	Off	Fast Flashing 5s	Off
Optistick Fail Other	Off	Off	Fast Flashing 5s
Oil Return Active	Constant On	Off	Constant On
DSP Firmware Upgrade	All three LEDs lights up in order (Green->Yellow->Red->Yellow...)		
IO Firmware Upgrade	All LEDs on with weak light		

## 6 TECHNICAL DATA

### 6.1. Detailed Product Rating Tables

Part Number	Power Rating		Input Current	Fuse or MCB (Type B)			Max Input Cable Size		Continuous Output Current	Overload Output Current	Maximum Output Cable Size		Maximum Motor Cable Length	
	kW	HP		A	Non UL	UL	mm <sup>2</sup>	awg			A	A	mm <sup>2</sup>	awg
CV-220070-1FHP	1.5	2	8.9	16	15	16	6	7	9.1	6	10	10	33	
CV-220120-1FHP	3	3	15.8	25	20	16	6	12	13.2	6	10	10	33	
CV-220160-1FHP	4	5.5	21.3	25	25	16	6	16	20.8	6	10	10	33	
CV-220200-1FHP	5.5	7.5	25.6	32	35	16	6	20	22	6	10	10	33	
CV-220070-1FCP	1.5	2	8.9	16	15	16	6	7	9.1	6	10	10	33	
CV-220120-1FCP	3	3	15.8	25	20	16	6	12	13.2	6	10	10	33	
CV-220160-1FCP	4	5.5	21.3	25	25	16	6	16	20.8	6	10	10	33	
CV-220200-1FCP	5.5	7.5	25.6	32	35	16	6	20	22	6	10	10	33	
CV-240140-3FHE	5.5	7.5	12	16	35*	6	10	14	18.2	6	10	10	33	
CV-240180-3FHE	7.5	10	16	25	35*	6	10	18	23.4	6	10	10	33	
CV-240240-3FHE	11	15	22	25	35*	6	10	24	28	6	10	10	33	
CV-240140-3FCE	5.5	7.5	12	16	35*	6	10	14	18.2	6	10	10	33	
CV-240180-3FCE	7.5	10	16	25	35*	6	10	18	23.4	6	10	10	33	
CV-240240-3FCE	11	15	22	25	35*	6	10	24	28	6	10	10	33	
CV-340300-3FHE	15	20	26.5	32	30	16	6	30	39.9	16	6	10	33	
CV-340390-3FHE	18.5	25	38	50	40	16	6	39	51.8	16	6	10	33	
CV-340460-3FHE	22	30	37.9	50	50	16	6	46	61.1	16	6	10	33	
CV-340580-3FHE	30	40	51.9	63	70	35	2	58	77.1	35	2	10	33	
CV-440300-3FCE	15	20	26.5	32	30	16	6	30	39.9	16	6	10	33	
CV-440390-3FCE	18.5	25	38	50	40	16	6	39	51.8	16	6	10	33	
CV-440460-3FCE	22	30	37.9	50	50	16	6	46	61.1	16	6	10	33	
CV-440580-3FCE	30	40	51.9	63	70	35	2	58	77.1	35	2	10	33	

**NOTE** Maximum permissible motor cable without the use of output filters is 10m with shielded cable and 20m with unshielded cable – for all ratings.

**NOTE** For UL compliant installations, branch circuit protection must be provided using UL Class CC or Class J Fuses Littlefuse part number L70QS035 of ratings\* shown in the table above.

### 6.2. Input Power Supply Requirements

Supply Voltage	200 – 240 RMS Volts for 230 Volt rated units, + / - 10% variation allowed.
	380 – 480 Volts for 400 Volt rated units, + / - 10% variation allowed.
Imbalance	Maximum 3% voltage variation between phase – phase voltages allowed.
	All Optidrive CoolVert units have phase imbalance monitoring. A phase imbalance of > 3% will result in the drive tripping.
Frequency	50 – 60Hz + / - 5% Variation.







82-CVQSG-IN\_V1.00

**Invertek Drives Ltd.** Offa's Dyke Business Park, Welshpool, Powys SY21 8JF United Kingdom  
Tel: +44 (0)1938 556868 Fax: +44 (0)1938 556869 [www.invertekdrives.com](http://www.invertekdrives.com)